

October 2024

## Spence™ High Capacity Float and Thermostatic Steam Trap

### WARNING

Failure to follow these instructions or to properly install and maintain this equipment could result in an explosion, fire and/or chemical contamination causing property damage and personal injury or death.

High Capacity Steam Trap must be installed, operated and maintained in accordance with federal, state and local codes, rules and regulations and Emerson instructions.

If leak develops in the system, service to the unit may be required. Failure to correct trouble could result in a hazardous condition.

Installation, operation and maintenance procedures performed by unqualified personnel may result in improper adjustment and unsafe operation. Either condition may result in equipment damage or personal injury. Only a qualified person shall install or service the High Capacity Steam Trap.

### Introduction

#### Scope of the Manual

This manual provides instructions for installation, maintenance and parts ordering for the High Capacity Steam Trap.

#### Product Description

FTH Series are float and thermostatic steam traps. Float actuates the valve via a hinged lever and linkage. Air vent is balanced-pressure design with stainless steel welded encapsulated bellows capable of discharging air and non-condensable gases continuously for heavy load process. Trap is cast iron bodied suitable for pressures to 200 psi / 13.8 bar with NPT connection.



Figure 1. High Capacity Steam Trap

### Principle of Operation

On startup, air and non-condensable gases enter the trap and are automatically vented through an accurate balanced-pressure internal thermostatic air vent. As condensate enters the trap, the float and lever mechanism is raised, lifting the valve off the seat, discharging the condensate. Condensate will continue to be discharged at the same rate at which it is entering. Any air or non-condensable gas that may accumulate will be continually and efficiently passed by the thermostatic air vent.

### Installation

#### WARNING

Personal injury, property damage, equipment damage or leakage due to escaping steam or bursting of pressure containing parts may result if this equipment is over pressured or is installed where service conditions could exceed the limits given in the

# High Capacity Steam Trap

## Specifications

The Specifications section gives some general specifications for the High Capacity Steam Trap.

### Available Configurations

**Types FTH-C2H9A and FTH-C2H9M:**

Steam differential pressure to 20 psig / 1.4 barg

**Types FTH-C5H9A and FTH-C5H9M:**

Steam differential pressure to 175 psig / 12.1 barg

**Types FTH-C5J9A and FTH-C5J9M:**

Steam differential pressure to 175 psig / 12.1 barg

### Maximum Operating Pressure<sup>(1)</sup>

**Type FTH-C2H9A and FTH-C2H9M:**

20 psig / 1.4 barg

**Types FTH-C5H9A, FTH-C5H9M,**

**FTH-C5J9A and FTH-C5J9M:** 175 psig / 12.1 barg

### Maximum Allowable Pressure<sup>(1)</sup>

200 psig / 13.8 barg

### Maximum Operating Temperature<sup>(1)</sup>

**Types FTH-C2H9A and FTH-C2H9M:** 259°F / 126°C

**Types FTH-C5H9A, FTH-C5H9M,  
FTH-C5J9A and FTH-C5J9M:** 450°F / 232°C

### Maximum Allowable Temperature<sup>(1)</sup>

450°F / 232°C

### Materials of Construction

**Head and Body:** Cast iron

**Bolts:** Steel

**Gaskets:** Compressed Graphite

**Lever Assembly:** Stainless steel

**Float, Plug and Seat:** Stainless steel

**Air Vent:** Stainless steel/Phosphorus Bronze  
or Monel

1. The pressure/temperature limits in this Instruction Manual and any applicable standard or code limitation should not be exceeded.

**specifications or where conditions exceed any ratings of the adjacent piping or piping connections.**

**To avoid such injury or damage, provide pressure-relieving or pressure-limiting device.**

FTH Series should be installed in an accessible position and location for easy servicing. The trap seat rating stamped on the nameplate, must be equal or greater than the maximum pressure differential across the trap. Install the trap straight and in a level position to ensure proper installation.

1. Determine where to install trap, based on the following requirements:
  - a. The trap must be located as closed as possible, and below the equipment to be drained.
  - b. The trap must be in a straight run of horizontal pipe as shown in Figure 2, and pitched to allow condensate to flow into trap inlet, and away from trap outlet.
  - c. Allow for enough space around the trap for servicing which may include removal of the body or cover, depending on the model you are installing.
2. Install a Y-strainer with a Blowdown valve in a pipe, ahead of steam trap. This prevents dirt from entering trap.
3. Install union fittings and a shutoff valve in inlet pipe and outlet pipe. This allows trap to be isolated when servicing.

4. Install a test valve in outlet pipe, and cap it. This allows trap to be tested. Cap is used as safety precaution when unit is not being tested.
5. Blowdown piping using full steam pressure for five minutes. This cleaning process will remove debris from pipe and oil from system.

## Maintenance



### WARNING

**To avoid personal injury, property damage or equipment damage caused by sudden release of pressure or explosion of accumulated gas, do not attempt any maintenance or disassembly without first isolating the equipment from system pressure and relieving all internal pressure from the equipment.**

When checked regularly and properly maintained, the High Capacity Steam Trap will provide optimum performance.

Recommended schedule:

- Initially, every 2 to 3 days after startup until system is clean.
- Due to normal wear that may occur, recommended to inspect the parts periodically and replace if necessary.




Figure 2. Typical Piping Diagram

## Note

**The frequency of inspection depends on the severity of service conditions or the requirements of state and federal laws.**

1. Inspect the joints for any leaks. Ensure to follow the "Removal from Service" and "Repair" procedure before addressing any joint leaks.
2. Clean strainers by opening blow down valve and allowing full steam pressure to flow out for a couple of minutes. Then, close valve.

## Removal from Service

1. Close inlet and outlet supply valves and allow unit to cool. If a test valve is installed, open this valve to relieve any pressure.
2. Remove bolts that attach cover to body and remove trap body.

## Repair

1. With body assembly removed from trap cover, remove pin that holds lever assembly to yoke. Inspect seat and pin for wear, replace if worn.
2. Inspect thermostatic element by placing it in boiling water to see if it closes. If it doesn't close, replace it.
3. Check alignment of pin and seat, adjust or replace parts as necessary. See Table 1.
4. Check float ball for damage shake float to make sure there is no fluid inside float. Replace if necessary.
5. Clean gasket surfaces and install new cover gasket.

## Return to Service

1. Reinstall trap body assembly on cover.
2. Insert and securely tighten drain plug.
3. Open supply valve on trap outlet side, slowly open the supply valve to the trap inlet.
4. Check for leaks and normal operation.

## Parts Ordering

When corresponding with your local Sales Office about High Capacity Steam Trap, always reference the size, service and serial number.

# High Capacity Steam Trap

**Table 1. FTH Series Torque Values for Bolt Covers**

TYPE	TORQUE	
	Ft-lbs	N•m
FTH-C2H9A and FTH-C2H9M	15	20.3
FTH-C5H9A and FTH-C5H9M	53	71.9
FTH-C5J9A and FTH-C5J9M	53	71.9

 [SpenceValve.com](https://www.SpenceValve.com)

## Emerson

### Americas

McKinney, Texas 75069 USA  
T +1 800 558 5853  
+1 972 548 3574

### Europe

Bologna 40013, Italy  
T +39 051 419 0611

### Asia Pacific

Singapore 128461, Singapore  
T +65 6777 8211

### Middle East and Africa

Dubai, United Arab Emirates  
T +971 4 811 8100

FCIM-20135-EN © 2024 Emerson Electric Co. All rights reserved 10/24.

Spence is a mark owned by a subsidiary of Emerson Electric Co. The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson Electric Co. does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson Electric Co. product remains solely with the purchaser.

